

Frank Gustrau

Fourth
Edition

RF and Microwave Engineering

Fundamentals of Wireless
Communications



WILEY

RF AND MICROWAVE ENGINEERING

RF AND MICROWAVE ENGINEERING

FUNDAMENTALS OF WIRELESS COMMUNICATIONS

Fourth Edition

Frank Gustrau

*Fachhochschule Dortmund
University of Applied Sciences and Arts
Germany*

(Translated from the original German language edition by Frank Gustrau)

WILEY



This edition first published 2025
© 2025 John Wiley & Sons Ltd

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, except as permitted by law. Advice on how to obtain permission to reuse material from this title is available at <http://www.wiley.com/go/permissions>.

The right of Frank Gustrau to be identified as the author of this work has been asserted in accordance with law.

Originally published in Germany as: **Hochfrequenztechnik, 4th Edition (ISBN: 978-3-446-47685-1) by Frank Gustrau**
© 2023 Carl Hanser Verlag, Munich. All rights reserved.

Registered Offices

John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, USA

John Wiley & Sons Ltd, New Era House, 8 Oldlands Way, Bognor Regis, West Sussex, PO22 9NQ, UK

For details of our global editorial offices, customer services, and more information about Wiley products visit us at www.wiley.com.

The manufacturer's authorized representative according to the EU General Product Safety Regulation is Wiley-VCH GmbH, Boschstr. 12, 69469 Weinheim, Germany, e-mail: Product_Safety@wiley.com.

Wiley also publishes its books in a variety of electronic formats and by print-on-demand. Some content that appears in standard print versions of this book may not be available in other formats.

Trademarks: Wiley and the Wiley logo are trademarks or registered trademarks of John Wiley & Sons, Inc. and/or its affiliates in the United States and other countries and may not be used without written permission. All other trademarks are the property of their respective owners. John Wiley & Sons, Inc. is not associated with any product or vendor mentioned in this book.

Limit of Liability/Disclaimer of Warranty

While the publisher and authors have used their best efforts in preparing this work, they make no representations or warranties with respect to the accuracy or completeness of the contents of this work and specifically disclaim all warranties, including without limitation any implied warranties of merchantability or fitness for a particular purpose. No warranty may be created or extended by sales representatives, written sales materials or promotional statements for this work. This work is sold with the understanding that the publisher is not engaged in rendering professional services. The advice and strategies contained herein may not be suitable for your situation. You should consult with a specialist where appropriate. The fact that an organization, website, or product is referred to in this work as a citation and/or potential source of further information does not mean that the publisher and authors endorse the information or services the organization, website, or product may provide or recommendations it may make. Further, readers should be aware that websites listed in this work may have changed or disappeared between when this work was written and when it is read. Neither the publisher nor authors shall be liable for any loss of profit or any other commercial damages, including but not limited to special, incidental, consequential, or other damages.

Library of Congress Cataloging-in-Publication Data Applied for:

Hardback ISBN: 9781394283460

Cover Design: Wiley

Cover Image: Courtesy of Frank Gustrau

Set in 10/12pt TimesLTStd by Straive, Chennai, India



Contents

Preface	x
Symbols and Abbreviations	xii
About the Companion Website	xvi
1 Introduction	1
1.1 Radiofrequency and Microwave Applications	1
1.2 Frequency Bands	4
1.3 Physical Phenomena in the High Frequency Domain	5
1.3.1 <i>Electrically Short Transmission Line</i>	5
1.3.2 <i>Transmission Line with Length Greater Than One-Tenth of Wavelength</i>	7
1.3.3 <i>Radiation and Antennas</i>	8
1.4 Outline of the Following Chapters	9
References	10
2 Electromagnetic Fields and Waves	11
2.1 Physical and Mathematical Basics	11
2.1.1 <i>Electrostatic Fields</i>	11
2.1.2 <i>Steady Electric Current and Magnetic Fields</i>	18
2.1.3 <i>Differential Vector Operations</i>	23
2.2 Maxwell's Equations	24
2.2.1 <i>Differential Form in the Time Domain</i>	24
2.2.2 <i>Differential Form for Harmonic Time Dependence</i>	25
2.2.3 <i>Integral Form</i>	26
2.2.4 <i>Constitutive Relations and Material Properties</i>	28
2.2.5 <i>Boundary Conditions</i>	31
2.3 Classification of Electromagnetic Problems	32
2.3.1 <i>Static Fields</i>	32
2.3.2 <i>Quasi-Static Fields</i>	33
2.3.3 <i>Coupled Electromagnetic Fields</i>	33
2.4 Skin Effect	33
2.5 Electromagnetic Waves	36
2.5.1 <i>Wave Equation and Plane Waves</i>	36
2.5.2 <i>Polarization of Waves</i>	40
2.5.3 <i>Reflection and Refraction</i>	42
2.5.4 <i>Spherical Waves</i>	48

2.6	Summary	50
2.7	Problems	51
	References	52
	Further Readings	52
3	Transmission Line Theory and Transient Signals on Lines	55
3.1	Transmission Line Theory	55
	3.1.1 <i>Equivalent Circuit of a Line Segment</i>	55
	3.1.2 <i>Telegrapher's Equation</i>	57
	3.1.3 <i>Voltage and Current Waves on Transmission Lines</i>	59
	3.1.4 <i>Load-Terminated Transmission Line</i>	62
	3.1.5 <i>Input Impedance</i>	64
	3.1.6 <i>Lossless Transmission Lines</i>	65
	3.1.7 <i>Low-loss Transmission Lines</i>	68
	3.1.8 <i>Lossless Transmission Line with Different Terminations</i>	69
	3.1.9 <i>Impedance Transformation with Lossless Lines</i>	75
	3.1.10 <i>Reflection Coefficient</i>	76
	3.1.11 <i>Smith Chart</i>	80
3.2	Transient Signals on Transmission Lines	84
	3.2.1 <i>Step Function</i>	84
	3.2.2 <i>Rectangular Function</i>	91
3.3	Eye Diagram	94
3.4	Summary	95
3.5	Problems	97
	References	98
	Further Readings	98
4	Transmission Lines and Waveguides	99
4.1	Overview	99
4.2	Coaxial Line	102
	4.2.1 <i>Specific Inductance and Characteristic Line Impedance</i>	102
	4.2.2 <i>Attenuation of Low-Loss Transmission Lines</i>	105
	4.2.3 <i>Technical Frequency Range</i>	107
	4.2.4 <i>Areas of Application</i>	108
4.3	Two-Wire Line	108
	4.3.1 <i>Characteristic Line Impedance</i>	109
	4.3.2 <i>Areas of Application</i>	109
4.4	Microstrip Line	110
	4.4.1 <i>Characteristic Line Impedance and Effective Permittivity</i>	110
	4.4.2 <i>Dispersion and Technical Frequency Range</i>	113
	4.4.3 <i>Areas of Application</i>	114
4.5	Stripline	114
	4.5.1 <i>Characteristic Line Impedance</i>	114
	4.5.2 <i>Technical Frequency Range</i>	115
	4.5.3 <i>Areas of Application</i>	115
4.6	Rectangular Waveguide	115
	4.6.1 <i>General Considerations</i>	116
	4.6.2 <i>Dominant Mode</i>	119
	4.6.3 <i>Higher Order Modes</i>	122

4.6.4	<i>Areas of Application</i>	123
4.6.5	<i>Excitation of Waveguide Modes</i>	125
4.6.6	<i>Cavity Resonators</i>	126
4.7	Substrate-Integrated Waveguide (SIW)	128
4.7.1	<i>Geometrical Structure and Electrical Characteristics</i>	128
4.7.2	<i>Microstrip-to-SIW Transition</i>	131
4.8	Three-Conductor Transmission Line	131
4.8.1	<i>Even and Odd Modes</i>	131
4.8.2	<i>Characteristic Line Impedances and Propagation Constants</i>	135
4.8.3	<i>Line Termination for Even and Odd Modes</i>	136
4.9	Problems	137
	References	138
5	Scattering Parameters	139
5.1	Multi-Port Network Representations	139
5.2	Normalized Power Waves	141
5.3	Scattering Parameters and Power	142
5.4	S-Parameter Representation of Network Properties	145
5.4.1	<i>Matching</i>	145
5.4.2	<i>Complex Conjugate Matching</i>	146
5.4.3	<i>Reciprocity</i>	148
5.4.4	<i>Symmetry</i>	148
5.4.5	<i>Passive and Lossless Circuits</i>	148
5.4.6	<i>Unilateral Circuits</i>	149
5.4.7	<i>Specific Characteristics of Three-Port Networks</i>	149
5.5	Calculation of S-Parameters	150
5.5.1	<i>Reflection Coefficients</i>	150
5.5.2	<i>Transmission Coefficients</i>	150
5.5.3	<i>Renormalization</i>	153
5.6	Signal Flow Method	154
5.6.1	<i>Source</i>	156
5.6.2	<i>One-port Network/Load Termination</i>	156
5.6.3	<i>Two-port Network</i>	156
5.6.4	<i>Three-port Network</i>	157
5.6.5	<i>Four-port Network</i>	157
5.7	S-Parameter Measurement	160
5.8	Problems	164
	References	166
	Further Readings	166
6	RF Components and Circuits	167
6.1	Equivalent Circuits of Concentrated Passive Components	167
6.1.1	<i>Resistor</i>	167
6.1.2	<i>Capacitor</i>	169
6.1.3	<i>Inductor</i>	170
6.2	Transmission Line Resonator	172
6.2.1	<i>Half-Wave Resonator</i>	172
6.2.2	<i>Quarter-Wave Resonator</i>	174

6.3	Impedance Matching	175
	6.3.1 <i>LC-Networks</i>	176
	6.3.2 <i>Matching Using Distributed Elements</i>	178
6.4	LC-Filter	181
	6.4.1 <i>Classical LC-Filter Design</i>	182
	6.4.2 <i>Butterworth Filter</i>	184
6.5	Transmission Line Filter	190
	6.5.1 <i>Edge-Coupled Line Filters</i>	191
	6.5.2 <i>Hairpin Filter</i>	195
	6.5.3 <i>Stepped Impedance Filter</i>	195
	6.5.4 <i>Parasitic Box Resonance</i>	195
	6.5.5 <i>Waveguide Filter</i>	198
6.6	Circulator	200
6.7	Power Divider	201
	6.7.1 <i>Wilkinson Power Divider</i>	201
	6.7.2 <i>Unequal Split Power Divider</i>	202
6.8	Branchline Coupler	204
	6.8.1 <i>Conventional 3 dB Coupler</i>	204
	6.8.2 <i>Unequal Split Branchline Coupler</i>	206
6.9	Rat Race Coupler	208
6.10	Directional Coupler	210
6.11	Balanced-to-Unbalanced Circuits	212
6.12	Electronic Circuits	213
	6.12.1 <i>Mixers</i>	215
	6.12.2 <i>Amplifiers and Oscillators</i>	217
6.13	RF Design Software	218
	6.13.1 <i>RF Circuit Simulators</i>	218
	6.13.2 <i>Three-Dimensional Electromagnetic Simulators</i>	219
6.14	Problems	222
	References	223
7	Antennas	225
7.1	Fundamental Parameters	225
	7.1.1 <i>Antennas as Wave-Type Converters</i>	225
	7.1.2 <i>Nearfield and Farfield</i>	225
	7.1.3 <i>Isotropic Radiator</i>	227
	7.1.4 <i>Radiation Pattern and Related Parameters</i>	228
	7.1.5 <i>Impedance Matching and Bandwidth</i>	233
7.2	Standard Types of Antennas	234
7.3	Mathematical Treatment of the Hertzian Dipole	237
7.4	Wire Antennas	241
	7.4.1 <i>Half-Wave Dipole</i>	241
	7.4.2 <i>Monopole</i>	244
	7.4.3 <i>Concepts for Reducing Antenna Height</i>	245
7.5	Slot Antennas	246
7.6	Aperture Radiators and Horn Antennas	248
	7.6.1 <i>Aperture Radiators</i>	248
	7.6.2 <i>Horn Antennas</i>	251

7.7	Planar Antennas	252
	7.7.1 <i>Rectangular Patch Antenna</i>	253
	7.7.2 <i>Circularly Polarizing Patch Antennas</i>	257
	7.7.3 <i>Planar Dipole and Inverted-F Antenna</i>	260
7.8	Antenna Arrays	261
	7.8.1 <i>Single Element Radiation Pattern and Array Factor</i>	261
	7.8.2 <i>Phased Array Antennas</i>	264
	7.8.3 <i>Beam Forming</i>	271
7.9	Modern Antenna Concepts	275
7.10	Problems	276
	References	277
8	Radio Wave Propagation	279
8.1	Propagation Mechanisms	279
	8.1.1 <i>Reflection and Refraction</i>	279
	8.1.2 <i>Absorption</i>	279
	8.1.3 <i>Diffraction</i>	280
	8.1.4 <i>Scattering</i>	282
8.2	Basic Propagation Models	284
	8.2.1 <i>Free Space Loss</i>	284
	8.2.2 <i>Attenuation of Air</i>	286
	8.2.3 <i>Reflection at Scattering Targets (Radar Cross-Section)</i>	287
	8.2.4 <i>Doppler Effect</i>	294
	8.2.5 <i>Plane Earth Loss</i>	296
	8.2.6 <i>Point-to-Point Radio Links</i>	299
	8.2.7 <i>Layered Media</i>	301
8.3	Path Loss Models	303
	8.3.1 <i>Multipath Environment</i>	304
	8.3.2 <i>Clutter Factor Model</i>	306
	8.3.3 <i>Okumura–Hata Model</i>	306
	8.3.4 <i>Physical Models and Numerical Methods</i>	307
8.4	Summary	310
8.5	Problems	311
	References	311
A	Mathematical Relations and Resonant Circuits	313
A.1	Coordinate Systems	313
	A.1.1 <i>Cartesian Coordinate System</i>	313
	A.1.2 <i>Cylindrical Coordinate System</i>	314
	A.1.3 <i>Spherical Coordinate System</i>	315
A.2	Characteristics of Resonant Circuits	316
	A.2.1 <i>Series Resonant Circuit</i>	316
	A.2.2 <i>Parallel Resonant Circuit</i>	321
A.3	Logarithmic Representation	326
	A.3.1 <i>Dimensionless Quantities</i>	326
	A.3.2 <i>Relative and Absolute Ratios</i>	326
	A.3.3 <i>Link Budget</i>	327

Preface

This textbook offers students a practical introduction to the field of high-frequency technology and the physical aspects of radio communication. Wireless technologies in the fields of communication (data networks, and mobile telephony), identification (RFID), navigation (GPS), and positioning (radar) are ubiquitous today. In the field of radio applications, comparatively high carrier frequencies have always been used, as this enables good utilization of the electromagnetic spectrum and the construction of efficient antennas. Cost-effective manufacturing processes and the use of computer-aided 3D design tools are constantly opening up new areas of application for radio technology with increasing bandwidths.

In the field of circuit technology, the use of higher data rates in circuits and the associated high-frequency signal components lead to new requirements in circuit design. Transmission lines suddenly require detailed consideration, couplings between neighboring components become more apparent, and there is unwanted radiation of electromagnetic waves. In design, distributed structures have increasing advantages over classic concentrated components. Digital engineers therefore also come into contact with terms like *characteristic line impedance* and *antenna*.

Today, a wide range of radio applications and high data rate communication can also be found in technical products that used to be part of mechanical engineering, such as the automobile. High-frequency technology is therefore – in its fundamentals – no longer a specialized discipline but a basic discipline for all engineers in the fields of electrical engineering, information and communication technology, and the related fields of mechatronics, automotive electronics, and biomedical engineering.

Considering the breadth of the subject of high-frequency technology, a sensible limitation of the material must of course be made for the presentation in this book. The first thing that distinguishes high-frequency technology from classical electrical engineering is the fact that the dimensions of the structures are no longer small in relation to the wavelength. The associated wave propagation processes lead to the typical high-frequency phenomena. The book therefore focuses on wave propagation processes, their description, their consequences, and their utilization in passive circuits and antenna structures.

Active electronic circuits and the entire field of high-frequency electronics, such as the design of amplifiers, mixers, and oscillators, are largely omitted from this book. In order to deal with this subject area in detail, an approach via the basics of electronics and semiconductor components would have to be chosen.

Numerical field simulations have become an integral part of the development process for high-frequency components and antennas. For this reason, numerous examples in this book were

calculated with the support of modern high-frequency circuit and field simulators. In detail, the following program packages were used:

- ADS (Advanced Design System) from Keysight Technologies
- CST Studio Suite from CST
- Empire XPU from IMST
- Pathwave electromagnetic (EM) Design (EMPro) from Keysight Technologies

The market for these software products is developing rapidly, so readers are advised to do their own research when choosing a suitable simulator. There are exercises at the end of each chapter. The solutions to the end-of-chapter problems are available on the Wiley Book Companion Site:

www.wiley.com/go/gustrauRF

The warm reception of this textbook by the readership has now made possible a fourth edition with technical extensions. In this edition, for example, the topics of radar backscatter cross-section, slot antenna, horn antenna, and substrate-integrated waveguide have been added and illustrated with additional examples.

The book's concept of combining physical-technical principles with numerical electromagnetic field simulations has proven its worth in courses and enables students to put their learning into practice and reflect critically on it at the same time.

I would like to take this opportunity to thank all my colleagues and students who have contributed to this book with their suggestions, either by asking questions in lectures or by reading individual chapters.

December 10, 2024

Frank Gustrau
Dortmund, Germany

Symbols and Abbreviations

Latin Letters

A	Area (m^2)
A_{dB}	Attenuation (dB)
\vec{A}	Magnetic vector potential (Tm)
A_{eff}	Effective antenna area (m^2)
\mathbf{A}	ABCD matrix (matrix elements have different units)
\vec{B}	Magnetic flux density (magnetic induction) (T; Tesla)
B	Bandwidth (Hz; Hertz)
BW	Bandwidth (angular frequency) (1/s)
c	Velocity of electromagnetic waves (m/s)
c_0	Velocity of electromagnetic waves in free space (m/s)
C	Capacitance (F; Farad)
$C(\varphi, \vartheta)$	Radiation pattern function (dimensionless)
C'	Capacitance per unit length (F/m)
D	Directivity (dimensionless)
\vec{D}	Electric flux density (C/m^2)
\vec{E}	Electric field strength (V/m)
f	Frequency (Hz)
f_c	Cut-off frequency (Hz)
\vec{F}	Force (N; Newton)
\vec{F}_C	Coulomb force (N)
\vec{F}_L	Lorentz force (N)
G	Conductance ($1/\Omega = S$; Siemens)
G	Gain (dimensionless)
G	Green's function (1/m)
G'	Conductance per unit length (S/m)
\vec{H}	Magnetic field strength (A/m)
\mathbf{H}	Hybrid matrix (matrix elements have different units)
I	Current (A; Ampere)
\mathbf{I}	Identity matrix (dimensionless)
j	Imaginary unit (dimensionless)
\vec{J}	Electric current density (A/m^2)
\vec{J}_S	Surface current density (A/m)
k	Coupling coefficient (dimensionless)
k	Wave number (1/m)
k_c	Cut-off wave number (1/m)

\vec{k}	Wave vector (1/m)
ℓ, L	Length (m)
L	Inductance (H; Henry)
L	Path loss (dimensionless)
L'	Inductance per unit length (H/m)
p	Power density (W/m ³)
P	Power (W; Watt)
P_{antenna}	Accepted power (W)
P_{inc}	Incoming power (W)
P_{rad}	Radiated power (W)
Q	Charge (C; Coulomb)
Q	Quality factor (dimensionless)
r	Radial coordinate in spherical coordinates (m)
R	Radial coordinate in cylindrical coordinates (m)
R	Resistance (Ω)
R_{DC}	Resistance for steady currents (Ω)
R_{ESR}	Equivalent series resistance (Ω)
R_{RF}	Resistance for radio frequencies (Ω)
R_{rad}	Radiation resistance (Ω)
R'	Resistance per unit length (Ω/m)
s_{kl}	Scattering parameter (dimensionless)
\mathbf{S}	Scattering matrix (dimensionless)
\vec{S}	Poynting vector (W/m ²)
\vec{S}_{av}	Average value of Poynting vector (W/m ²)
t	Time (s; Second)
T	Period (s)
$\tan \delta$	Loss tangent (dimensionless)
U	Voltage (V; Volt)
\vec{v}	Velocity (m/s)
v_{ph}	Phase velocity (m/s)
v_{gr}	Group velocity (m/s)
V	Volume (m ³)
w_e	Electric energy density (J/m ³)
W_e	Electric energy (J; Joule)
w_m	Magnetic energy density (J/m ³)
W_m	Magnetic energy (J)
x, y, z	Cartesian coordinates (m)
Y	Admittance (S; Siemens)
\mathbf{Y}	Admittance matrix (S)
Z_A	Load impedance (Ω)
Z_{in}	Input impedance (Ω)
Z_F	Characteristic wave impedance (intrinsic impedance) (Ω)
Z_{F0}	Characteristic wave impedance of free space (Ω)
Z_0	Characteristic line impedance (Ω)
	Port reference impedance (Ω)
$Z_{0,\text{cm}}$	Common mode line impedance (Ω)
$Z_{0,\text{diff}}$	Differential mode line impedance (Ω)
Z_{0e}	Even mode line impedance (Ω)
Z_{0o}	Odd mode line impedance (Ω)
\mathbf{Z}	Impedance matrix (Ω)

Greek Letters

α	Attenuation coefficient (1/m)
β	Phase constant (1/m)
γ	Propagation constant (1/m)
δ	Skin depth (m)
δ	Decay constant (1/s)
Δ	Laplace operator (1/m ²)
$\epsilon = \epsilon_0 \epsilon_r$	Permittivity (As/(Vm))
ϵ_0	Permittivity of free space (As/(Vm))
ϵ_r	Relative permittivity (dimensionless)
$\epsilon_{r,eff}$	Effective relative permittivity (dimensionless)
η	Radiation efficiency (dimensionless)
η_{total}	Total radiation efficiency (dimensionless)
ϑ	Elevation angle (rad)
ϑ_{iB}	Brewster angle (rad)
ϑ_{ic}	Critical angle (rad)
λ	Wavelength (m)
λ_W	Wavelength inside waveguide (m)
$\mu = \mu_0 \mu_r$	Permeability (Vs/(Am))
μ_0	Permeability of free space (Vs/(Am))
μ_r	Relative permeability (dimensionless)
ρ	Volume charge density (C/m ³)
ρ_S	Surface charge density (C/m ²)
σ	Electric conductivity (S/m; Siemens/m)
σ	Radar cross-section (m ²)
φ	Phase angle (rad)
φ	Azimuth angle (rad)
φ_0	Initial phase (rad)
ϕ	Scalar electric potential (V)
Ψ_e	Electric flux (As)
Ψ_m	Magnetic flux (Wb, Weber) (Vs)
ω	Angular frequency (1/s)
∇	Nabla operator (1/m)

Abbreviations

5G	Fifth Generation Mobile Communication Standard
ADS	Advanced Design System
Balun	Balanced-to-Unbalanced
BEM	Boundary Element Method
CAD	Computer Aided Design
CW	Continuos Wave (Monofrequent signal)
dB	Decibel
dB _i	Decibel (Reference: isotropic radiator)
dB _{sm}	Decibel (Reference: 1 m ² , square meter)
DC	Direct Current
DFT	Discrete Fourier Transform
DIN	Deutsche Industrienorm (German institute for standardization)
DUT	Device Under Test
EIRP	Equivalent Isotropically Radiated Power

EM	ElectroMagnetic
EMC	ElectroMagnetic Compatibility
FDTD	Finite-Difference Time-Domain
FEM	Finite Element Method
FR4	Glass reinforced epoxy laminate
GPS	Global Positioning System
GSM	Global System for Mobile communication
GTD	Geometrical Theory of Diffraction
GUI	Graphical User Interface
HPBW	Half Power Beam Width
ICNIRP	International Commission on Non-Ionizing Radiation Protection
IFA	Inverted-F Antenna
IoT	Internet of Things
ISM	Industrial, Scientific, Medical
ISO	International Organization for Standardization
ITU	International Telecommunication Union
LNA	Low-Noise Amplifier
LOS	Line of Sight
LTCC	Low-Temperature Cofired Ceramics
LTE	Long Term Evolution (Fourth Generation Mobile Communication Standard)
MIMO	Multiple-Input Multiple-Output
MMIC	Monolithic Microwave Integrated Circuits
MoM	Method of Moments
NLOS	Non Line of Sight
PEC	Perfect Electric Conductor
PML	Perfectly Matched Layer
RADAR	Radio Detection and Ranging
RCS	Radar Cross-Section
RF	Radio Frequency
RFID	Radio Frequency Identification
RMS	Root Mean Square
SIW	Substrate-Integrated Waveguide
SMD	Surface Mounted Device
SNR	Signal-to-Noise Ratio
TEM	Transversal Electromagnetic
UMTS	Universal Mobile Telecommunication System
UTD	Uniform Theory of Diffraction
UWB	Ultra-WideBand
VNA	Vector Network Analyzer
VSWR	Voltage Standing Wave Ratio
WLAN	Wireless Local Area Network

Physical Constants

μ_0	$4\pi \cdot 10^{-7} \text{ Vs}/(\text{Am})$	Permeability of free space
ϵ_0	$8.854 \cdot 10^{-12} \text{ As}/(\text{Vm})$	Permittivity of free space
c_0	$2.99792458 \cdot 10^8 \text{ m/s}$	Speed of light in vacuum
e	$1.602 \cdot 10^{-19} \text{ C}$	Elementary charge
Z_{F0}	$376.730 \dots \Omega \approx 120\pi \Omega$	Wave impedance of free space

About the Companion Website

This book is accompanied by a companion website:

www.wiley.com/go/gustrauRF



The website includes solution manuals.

1

Introduction

1.1 Radiofrequency and Microwave Applications

Today at home or on the move, every one of us uses devices that employ wireless technology to an increasing extent. Figure 1.1a shows a selection of wireless communication, navigation, identification and detection applications.

In the future we will see a growing progression of the trend to apply components and systems of high-frequency technology in new areas of application. Development and maintenance of such systems requires an extensive knowledge of high-frequency behavior of basic elements (e.g. resistors, capacitors, inductors, transmission lines, transistors), components (e.g. antennas), circuits (e.g. filters, amplifiers, mixers) including physical issues such as electromagnetic wave propagation (Figure 1.1b).

Table 1.1 shows a number of standard RF and microwave applications and their associated frequency bands [1–3]. The applications include terrestrial voice and data communication, which means cellular networks and wireless communication networks, as well as terrestrial and satellite-based broadcasting systems. Wireless identification systems (RFID) within *industrial, scientific, and medical* (ISM) bands enjoy increasing popularity among cargo traffic and logistics businesses. As for the field of navigation, GPS should be pointed out, which today is already installed in numerous vehicles and mobile devices. Looking at the automotive sector, radar systems are being used to monitor the surrounding area or serve as sensors for driver assistance systems.

The various application areas are developing rapidly. Let's take a look at the development of mobile telephony as an example. In the early days of mobile telephony, the focus was on voice communication. Analog terminals were bulky and expensive. With the second generation (2G/GSM), digital technology was introduced to mobile telephony in the 1990s. Terminals became more compact and affordable for the masses. In addition to voice communication, a text service or short message service (SMS) was established. At the turn of the millennium, the third generation (3G/UMTS) saw the development of mobile broadband applications with the possibility of using multimedia content (photo, video, music) and the Internet on the move. Under the influence of the new technical possibilities, the operating concepts of the end devices changed (touchscreen instead of the keyboard) and the equipment of the devices became more complex (e.g. built-in cameras).




Figure 1.1 (a) Examples of wireless applications and (b) RF components and propagation of electromagnetic waves.

With the fourth-generation mobile communications standard (4G/LTE-Advanced¹) from around 2010, mobile broadband access was further developed, data rates were increased and capacity (number of simultaneously active subscribers in the network) was increased. Inexpensive devices and tariffs led to mobile broadband access for everyone. In addition to fast mobile broadband access, an expansion of the LTE standard (NB-IoT²) also included applications in the area of Industry 4.0 and the Internet of Things. The data rates in this field of application are comparatively low, but the requirements for energy efficiency and reliability are very high.

A fifth-generation mobile communications standard (5G) is currently being established in order to meet increasing requirements and open up further fields of application for mobile communications [4, 5]. A total of three application scenarios are being addressed:

- Improvements in mobile broadband applications (eMBB = enhanced Mobile Broadband): Higher data rates and reduced delay rates for VR³ and AR⁴ applications, among others.
- Communication between a large number of low-cost and energy-efficient devices for industrial applications (mMTC = massive Machine Type Communications).
- Applications with low latency and high reliability for autonomous driving, for example (URLLC = Ultra Reliable Low Latency Communications).

¹ LTE-Advanced is often simply abbreviated as LTE for reasons of language economy. In any case, this refers to fourth-generation mobile communications or further developments within this generation.

² Narrow Band Internet of Things.

³ Virtual Reality.

⁴ Augmented Reality.

Table 1.1 Wireless applications and frequency ranges

Cellular mobile telephony		
GSM	Global System for Mobile Communication (2nd generation mobile communication standard)	900 MHz, 1800 MHz
UMTS	Universal Mobile Telecommunications System (3rd generation mobile communication standard)	2100 MHz
LTE	Long Term Evolution (4th generation mobile communication standard)	800 MHz, 1800 MHz, 2600 MHz
5G	5th generation mobile communication standard (*) Other frequency ranges planned	700 MHz, 3400 ... 3800 MHz, 28 GHz (*)
Tetra	Trunked radio	450 MHz
Wireless networks		
WLAN	Wireless local area network	2.45 GHz, 5 GHz
Bluetooth	Short range radio	2.45 GHz
Navigation		
GPS	Global Positioning System	1.2 GHz, 1.575 GHz
Identification		
RFID	Radio-Frequency Identification	13.56 MHz, 868 MHz, 2.45 GHz, 5 GHz
Radio broadcasting		
FM	Analog broadcast transmitter network	87.5 ... 108 MHz
DAB	Digital Audio Broadcasting	200 MHz
DVB-T2	Digital Video Broadcasting – Terrestrial	470 ... 690 MHz
DVB-S	Digital Video Broadcasting – Satellite	10.7 ... 12.75 GHz
Radar applications		
SRR	Automotive short range radar	24 GHz
ACC	Adaptive cruise control radar	77 GHz

Significant changes have been made to the radio interface, among other things, in order to meet the requirements of the various application scenarios. All previous standards operated in the frequency range below 3 GHz (Table 1.1). The radio interface of the fifth generation of mobile communications (5G NR = 5G New Radio) distinguishes between the frequency range FR1 (Frequency Range 1) below 6 GHz and the frequency range FR2 (Frequency Range 2) above 24.25 GHz. The low frequencies (e.g. 700 MHz) are suitable for good network coverage in the area and for coverage in critical building areas (e.g. basements). In the 3–4 GHz range, propagation conditions are similar to those of the previous standards. The newly added millimeter wave range (e.g. 28 GHz) allows very high data rates and a very high capacity in small spatial areas. Multi-antenna concepts with beamforming can be realized at high frequencies with the help of very compact antenna systems. Overall, the development in the field of mobile radio is not foreseeable. In this book, we will lay the *physical-technical* foundations for understanding the *high-frequency technical aspects* of the various radio technologies and, for example, discuss antenna technology and wave propagation on lines, in circuits and in complex spatial environments.

However, high-frequency technology does not only play a decisive role in radio technology. Due to the increasing processing speed of digital circuits, high-frequency signal components are

emerging, which means that high-frequency engineering design methods are also used for fast digital circuits.

Due to its proximity to electromagnetic field theory, high-frequency technology also extends into the field of electromagnetic compatibility.⁵ On the one hand, the measurement setups used here with cables and antennas are based directly on high-frequency principles. On the other hand, non-compliance with specified EMC limits generally requires a detailed analysis of the situation in order to achieve improvements. The inclusion of high-frequency aspects often leads to significant progress.

1.2 Frequency Bands

For better orientation, the electromagnetic spectrum is divided into a number of frequency bands. Various naming conventions have been established in different parts of the world, which often are used in parallel. Table 1.2 shows a customary classification of the frequency range from 3 kHz to 300 GHz into eight frequency decades according to a recommendation of the *International Telecommunications Union* (ITU) [6].

Figure 1.2a shows commonly used designation of different frequency bands according to IEEE standards [7]. The unsystematic use of characters and band ranges, which has developed over the years though can be regarded as a clear disadvantage. A more recent naming convention according

Table 1.2 Frequency denomination according to ITU

Frequency range	Denomination
3 ... 30 kHz	VLF – Very Low Frequency
30 ... 300 kHz	LF – Low Frequency
300 kHz ... 3 MHz	MF – Medium Frequency
3 ... 30 MHz	HF – High Frequency
30 ... 300 MHz	VHF – Very High Frequency
300 MHz ... 3 GHz	UHF – Ultra High Frequency
3 ... 30 GHz	SHF – Super High Frequency
30 ... 300 GHz	EHF – Extremely High Frequency




Figure 1.2 Denomination of frequency bands according to different standards: (a) denomination according to IEEE Std. 521-2002 and (b) according to NATO.

⁵ Electromagnetic compatibility (EMC) deals with the avoidance of interfering interactions between technical devices. Devices are tested for compliance with technical limits in standardized measurement setups.